

• ● ○ • nuance audio



User Guide

[Manuale utente](#)

[Guide utilisateur](#)

[Guía del usuario](#)

[Benutzerhandbuch](#)

Activation

Attivazione Activation Activación Aktivierung



1. Download the Nuance Audio App

Scarica l'app Nuance Audio

Téléchargez l'application Nuance Audio

Descargue la aplicación Nuance Audio

Die Nuance Audio App herunterladen




2. Sign in & pair

Accedi e associa

Connectez-vous et jumelez

Inicie sesión y empareje

Anmelden und koppeln



3. Press & hold until the blue LED blinks

Tieni premuto finché il LED blu non lampeggia

Maintenez enfoncé jusqu'à ce que la LED bleue clignote

Mantenga presionado hasta que el LED azul parpadee

Gedrückt halten, bis die blaue LED blinkt


Multifunction button

Pulsante multifunzione

Bouton multifonction

Botón multifunción

Multifunktionstaste




Cycle volume levels Press

Ciclo dei livelli di volume Premere

Niveaux de volume du cycle Appuyez

Cambio niveles de volumen Presionar

Lautstärkestufen einstellen Drücken



On/Off Press & hold

On/Off Tieni premuto

On/Off Appuyez et maintenez

Encendido/apagado Mantener pulsado

On/Off Drücken & halten

Audio modes

Modalità audio Modes audio Modos de audio Audio-Modi

Frontal

Amplifying sounds
in front of you

Frontale

Per amplificare i suoni davanti a te

Devant

Pour amplifier les sons devant vous

Frontal

Amplifica los sonidos frente a ti

Vorne

Geräusche vor Ihnen verstärken

All-around

Amplifying sounds
all around you

Tutto intorno

Per amplificare i suoni intorno a te

Tout autour


Pour amplifier les sons autour de vous

Alrededor

Amplifica los sonidos a tu alrededor

Rundum

Geräusche rundum verstärken



Switch audio modes Double tap

Cambio modalità audio Tocca due volte




Changement de mode audio Effleurez deux fois

Cambiar modos de audio Doble pulsación

Audiomodus umschalten Doppeltippen

Charging

Ricarica Chargement Carga Aufladen




Ricarica Chargement Carga Aufladen

Support Supporto Assistance Ayuda Support

nuanceaudio.com/contact-us



This user guide is applicable to OAW5001, OAW5002, OAW5004 Nuance Audio Glasses models

 Luxottica Group S.p.A. Piazzale Cadorna 3, 20123 Milan, Italy



Raccolta carta
Papier y cartón

