

Nuance Audio Plus

Quick Start Guide

IT Guida rapida FR Guide de démarrage rapide ES Guía de inicio rápido DE Schnellstart-Anleitung

Start here

IT Inizia qui FR Commencez ici ES Empieza aquí DE Hier beginnen

1

Download the Nuance Audio app

- IT Scarica la Nuance Audio app
FR Téléchargez l'application Nuance Audio app
ES Descargue la Nuance Audio app
DE Laden Sie die Nuance Audio app herunter




App Store

Google Play

2

Slide the switch to turn on and pair

- IT Fai scorrere l'interruttore per accendere ed effettuare l'abbinamento
FR Faites glisser le bouton pour allumer et appairer
ES Desliza el interruptor para encender y emparejar
DE Schieben Sie den Schalter zum Einschalten und Koppeln




Bluetooth pairing indicators

IT Indicatori di abbinamento Bluetooth FR Indicateurs d'appairage avec le Bluetooth ES Indicadores de emparejamiento Bluetooth DE Bluetooth-Kopplungsanzeigen

Blinking blue LED – Pairing in progress Solid blue LED – Pairing successful

- IT LED blu lampeggiante – Abbinamento in corso
LED blu fisso – Abbinamento riuscito
FR LED bleue clignotante : Appairage en cours
LED bleue fixe : Appairage réussi
ES LED azul parpadeante – Emparejamiento en curso
LED azul sólido – Emparejamiento correcto
DE Blinkende blaue LED – Kopplung läuft
Konstant blaue LED – Kopplung erfolgreich abgeschlossen




Charging

IT Ricarica FR Chargement ES Carga DE Aufladen


1




2



3





How to save power IT Come risparmiare energia FR Comment réduire la consommation d'énergie ES Cómo ahorrar batería DE Wie man Energie spart



Fold to sleep

- IT Piega per mettere in stand by
FR Plier pour mettre en veille
ES Pliegue para reposar
DE Zuklappen für den Ruhemodus




Unfold to wake

- IT Apri per riattivare
FR Déplier pour allumer
ES Despliegue para encender
DE Aufklappen, um zu aktivieren

Cleaning IT Pulizia FR Nettoyage ES Limpieza DE Reinigung

Clean with a damp cloth, Do not rinse or spray

- IT Pulire con un panno umido, non risciacquare né utilizzare spray
FR Nettoyez avec un chiffon humide. Ne rincez pas et n'utilisez pas de spray.
ES Limpiar con un paño húmedo. No enjuagar ni pulverizar
DE Mit feuchtem Brillenputztuch reinigen, kein Wasser und keine Sprays benutzen



Support nuanceaudio.com/contact-us

IT Supporto FR Assistance ES Soporte DE Hilfe

This quick start guide is applicable to AW5005, AW5006, AW5007 Nuance Audio™ Plus models
IT Questa guida rapida è applicabile ai modelli Nuance Audio™ Plus AW5005, AW5006, AW5007
FR Ce guide de démarrage rapide s'applique aux modèles de Nuance Audio™ Plus AW5005, AW5006 et AW5007
ES Esta guía de inicio rápido es aplicable a los modelos de Nuance Audio™ Plus AW5005, AW5006 y AW5007
DE Diese Schnellstart-Anleitung ist für die Modelle Nuance Audio™ Plus AW5005, AW5006 und AW5007 gültig


Luxottica Group S.p.A.
Piazzale Cadorna 3,
20123 Milan, Italy

