




How to charge



Ready to charge your Nuance Audio Plus?


Step 1

First connect your Charging Pad using a standard USB-C charger or USB-C power source (minimum 5V) to connect the supplied Charging Pad and USB-C cable.



Step 2

Then, fold your Nuance Audio Plus and place them directly on the Charging Pad exactly as shown. The magnets inside the Charging Pad will help position the Glasses correctly.







How to know when your glasses are charged?

Orange LED

Charging is in progress.

Green LED

Glasses are fully charged (at least 96%).





Battery level indications

When the Glasses are picked up, the frame LED lights up for 3 seconds to indicate the battery level.

Red LED

Battery level below 20%

Orange LED

Battery level between 21% and 89%

Green LED

Battery level above 90%





For the most updated Instructions
for Use please follow this link

[↗ View instruction for use](#)