


Hearing configurations: Background noise




How to adjust background noise?

Nuance Audio Plus allows you to **customize the strength of background noises in your environment** while using your Nuance Audio Plus.

For example, sounds such as traffic, air conditioning, whirring fans, rain, vacuuming, and so on can be adjusted.




To adjust the levels, tap on the Background Noise tab in Homepage.



You can choose to adjust them in three ways (lowered, standard, and heightened).




How to adjust background noise?




Background noise: Lowered

You'll minimize the background noise, making it less noticeable.



Background noise: Standard

You'll hear the background at the original sound level.



Background noise: Heightened

You'll hear the background noise louder and more clearly.



For the most updated Instructions
for Use please follow this link

[↗ View instruction for use](#)